

Damper actuator for adjusting dampers in technical building installations

- Air damper size up to approx. 3.2 m²
- Torque motor 16 Nm
- Nominal voltage AC/DC 24 V
- Control Open/close (unsuitable for 3-point controls)
- Running time motor 7 s



Technical data

Electrical data	Nominal voltage	AC/DC 24 V
	Nominal voltage frequency	50/60 Hz
	Nominal voltage range	AC 19.228.8 V / DC 21.628.8 V

Power consumption in operation	15 W
Power consumption in rest position	2 W
Power consumption for wire sizing	26 VA
Power consumption for wire sizing note	Imax 20 A @ 5 ms
Connection supply / control	Cable 1 m, 3x 0.75 mm ²
Parallel operation	Yes (note the performance data)

Functional data Torque motor 16 Nm

Minimum angle of rotation

Protection class IEC/EN

Safety data

Torque motor	10 IVIII
Direction of motion motor	selectable with switch 0 (ccw rotation) / 1 (cw
	rotation)

Manual overridewith push-button, can be lockedAngle of rotationMax. 95°Angle of rotation notecan be limited on both sides with adjustable mechanical end stops

Min. 30°

III, Safety Extra-Low Voltage (SELV)

Running time motor 7 s / 90°

Sound power level, motor 63 dB(A)

Mechanical interface Universal shaft clamp reversible 12...26.7 mm

Position indication Mechanical, pluggable

Power source UL

Degree of protection IEC/EN

Degree of protection NEMA/UL

Enclosure

UL Enclosure Type 2

EMC

CE according to 2014/30/EU

Certification IEC/EN IEC/EN 60730-1 and IEC/EN 60730-2-14

UL Approval cULus according to UL60730-1A, UL60730-2-14

and CAN/CSA E60730-1

The UL marking on the actuator depends on

the production site, the device is UL-compliant in any case

Hygiene test

According to VDI 6022 Part 1 / SWKI VA

Type of action

Type 1

www.belimo.com



Technical data Safety data Rated impulse voltage supply / control 0.8 kV 3 Pollution degree Ambient humidity Max. 95% RH, non-condensing Ambient temperature -30...40°C [-22...104°F] Caution: 40...50°C utilisation possible only Ambient temperature note under certain restrictions. Please contact your supplier. -40...80°C [-40...176°F] Storage temperature Servicing maintenance-free Weight Weight 1.7 kg

Safety notes



- This device has been designed for use in stationary heating, ventilation and air-conditioning
 systems and must not be used outside the specified field of application, especially in aircraft
 or in any other airborne means of transport.
- Outdoor application: only possible in case that no (sea) water, snow, ice, insolation or aggressive gases interfere directly with the device and that it is ensured that the ambient conditions remain within the thresholds according to the data sheet at any time.
- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- · Cables must not be removed from the device.
- Self adaptation is necessary when the system is commissioned and after each adjustment of the angle of rotation (press the adaptation push-button once).
- To calculate the torque required, the specifications supplied by the damper manufacturers
 concerning the cross-section and the design, as well as the installation situation and the
 ventilation conditions must be observed.
- The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

Product features

Simple direct mounting

Simple direct mounting on the damper shaft with a universal shaft clamp, supplied with an anti-rotation device to prevent the actuator from rotating.

Manual override

Manual override with push-button possible (the gear train is disengaged for as long as the button is pressed or remains locked).

Adjustable angle of rotation

Adjustable angle of rotation with mechanical end stops. A minimum permissible angle of rotation of 30° must be allowed for.

High functional reliability


The actuator is overload protected, requires no limit switches and automatically stops when the end stop is reached.

Home position

The first time the supply voltage is switched on, i.e. at the time of commissioning, the actuator carries out an adaptation, which is when the operating range and position feedback adjust themselves to the mechanical setting range.

The detection of the mechanical end stops enables a gentle approach to the end positions, thus protecting the actuator mechanics.

The actuator then moves into the position defined by the control signal.





Accessories

Electrical accessories	Description	Туре
	Auxiliary switch 1x SPDT add-on	S1A
	Auxiliary switch 2x SPDT add-on	S2A
	Feedback potentiometer 140 Ω add-on	P140A
	Feedback potentiometer 1 kΩ add-on	P1000A
	Feedback potentiometer 10 k Ω add-on	P10000A
	Adapter for auxiliary switch and feedback potentiometer, Multipack 20	Z-SPA
	pcs.	

Mechanical accessories

Description	Туре
Actuator arm for standard shaft clamp	AH-GMA
Ball joint suitable for damper crank arm KH8 / KH10	KG10A
Damper crank arm Slot width 8.2 mm, clamping range ø1425 mm	KH10
Anti-rotation mechanism 230 mm, Multipack 20 pcs.	Z-ARS230
Mounting kit for linkage operation for flat installation	ZG-GMA
Position indicator, Multipack 20 pcs.	Z-PI

^{*} Adapter Z-SPA

It is imperative that this adapter will be ordered if an auxiliary switch or a feedback potentiometer is required and if at the same time the shaft clamp is installed on the rear side of the actuator (e.g. with short shaft installation).

Electrical installation



Supply from isolating transformer.

Parallel connection of other actuators possible. Observe the performance data.


Wire colours:

1 = black

2 = red

3 = white


Wiring diagrams



1	2	3		
	7	\	(1)	(
	~	~	(7



Operating controls and indicators



Direction of rotation switch

Switch over: Direction of rotation changes

2 Push-button and LED display green

Off: No power supply or malfunction

On: In operation

Press button: Triggers angle of rotation adaptation, followed by standard mode

3 Push-button and LED display yellow

Off: Standard mode

On: Adaptation or synchronisation process active

Press button: No function

4 Manual override button

Press button: Gear train disengages, motor stops, manual override possible
Release Gear train engages, synchronisation starts, followed by standard

button: mode

Check power supply connection

2 Off and 3 On Possible wiring error in power supply

Installation notes

Negative torque


Max. 50% of the torque (Caution: Application possible only with restrictions. Please contact your supplier.)

Dimensions

Spindle length



Clamping range



*Option: Shaft clamp mounted below: If an auxiliary switch or a feedback potentiometer is used the adapter Z-SPA is required.

